




WARNING!

POWER CONSOLE TOP ONLY

YAMAHA
RHINO

- BE SURE TO FOLLOW THESE INSTRUCTIONS BEFORE INSTALLATION
- BE SURE ALL HARDWARE IS PROPERLY SECURED BEFORE TRANSIT
- DO NOT SIT, REST, OR PLACE ANY OVERSIZED OBJECTS ON THE CENTER CONSOLE
- BE SURE AREA AROUND ANY ELECTRICAL COMPONENTS IS DRY BEFORE CHARGING
- THIS ITEM IS NOT DESIGNED TO SUSTAIN EXTREME WEATHER CONDITIONS OR SUBMERSION



(1) The electrical top is ready to be installed without any additional wiring required. All wires are ready to be connected to their corresponding electrical points. (2) Unscrew and remove all top screws which secure the top section of the center console. Then carefully remove the top section without damaging the lower dashboard section. (3) Locate the battery compartment inside the middle section of the center console. Be sure the battery (purchase separately) fits securely inside the battery compartment before securing the top section. (4) Then gently slide the electrical top section of the center console to fit directly above the middle section. Be careful as not to scratch any parts on the dashboard of the vehicle. Secure the top section on the middle section with the provided hardware. Do not tighten yet.

(5) Inside the center console, connect all wires to the corresponding points on the battery. Then check on the electrical top console (LED should be on when charging) to make sure all wires and connections are working properly. (6) The console can be used to charge/recharge various electronic devices with the provided double-ended charger cable.

IMPORTANT: Be sure the middle section of the center console is not in the way of the throttle linkage near the pedal.

Be sure the center console is secured before operating the vehicle. Be careful of any sharp corners of the center console.

DO NOT OVER TIGHTEN